



SILVERTON

MARINE CORPORATION

AN EMPLOYEE OWNERSHIP COMPANY

SERVICE BULLETIN


BULLETIN # 01-04
DATE: 1/04/2004
SUBJECT: 48 CONVERTIBLE
FUEL GAUGE
HULL #s: #37 to #

It has recently come to our attention the fuel gauge on your boat maybe missing the resister on the ignition feed that steps down the voltage to the gauge. Therefore Silverton will replace the fuel gauge due to possible damage from improper voltage. Below is the photo showing the resister. The below instructions describe how to install the fuel gauge. Estimated time to complete this installation is 30 minutes.



FARIA FUEL GAUGE 24V CONFIGURATION

PLACE RESISTOR BOARD ONTO THE
IGN POST ON THE BACK OF GAUGE.
THE POST ON THE RESISTOR
BOARD WILL THEN BE USED IN PLACE
OF THE IGN POST ON THE GAUGE



24V RESISTOR BOARD