



SERVICE BULLETIN

BULLETIN # 08-04
DATE: 9/13/2004
SUBJECT: 48 CONVERTIBLE
LIVE WELL SWITCH
HULL #s: STNAM035, 36, 37, 39, 40, 45, 48, 51, 54, 55, 60, 61, 62, 64, 66, 68

It has recently come to our attention the switch to operate the livewell pump on your 48C may possibly oxidize causing the switch to be inoperable.

In order to remove this potential we are supplying a SPST switch with rubber boot cover for a replacement.

The instructions below describe how to replace the switch.

Estimated time to complete this installation is 30 minutes.

- 1- Turn DC power off to the live well pump at the main DC panel located in the salon.
- 2- Remove the 4 screws at the switch plate and pull switch out away from the hull.
- 3- Remove wires from back of switch.(careful not to drop wires through the hole)
- 4- Install wires on new switch.
- 5- Re-install switch. (switch has same screw pattern)
- 6- Turn DC power back on and test switch.